



**CRAFTING IDEA**

**GB**

# Copper-coloured diamond-shaped jewellery pendant

[WWW.RAYHER.COM](http://WWW.RAYHER.COM)



## Used items:

- 36 055 000** Casting mould: Pendant Diamond
- 34 166 000** Jewellery-cement
- 22 657 000** Deco-metal application milk
- 21 715 24** Deco-metal flakes, copper
- 22 658 000** Deco-metal protective varnish
- 22 656 21** Ring wide, platinum
- 22 659 000** Metal element chain w.clasp, 2 mm ø, silver
- 89 541 00** Flat round pliers for jewellery, 13.5 cm



## Instructions:

- 1** To cast the jewellery-cement-pendant you need an elastic casting mould, a digital scale and a small plastic container as well a craft wooden stick for stirring. The mixing ratio:  
1 part of water : 5 parts of jewellery-cement.
- 2** First, weigh the water in a cup and then add gradually the jewellery-cement. Stir it with a craft wooden stick until a homogeneous mass arises.
- 3** Now, you can fill the mould with the casting compound. The mould should always be cleaned with detergent and water before being filled. If bubbles occur, you should tap few times the mould on the pad.
- 4** The temperature and the current air humidity determine the drying time. It is however advisable to demould the pendant only the next day. Allow post drying.
- 5** The upper side, in other words the subsequent reverse side, you can rectify with some fine sandpaper.
- 6** In order to decorate the jewellery-cement pendant with a decorative metal, sketch out the cutting lines by using pencil and ruler. Spread the application milk accurately with a fine brush on, free rein. Let it dry for about 5 minutes.
- 7** Lay on crease-free the flake-shaped decorative metal on the lines covered by the application milk. Press slightly the decorative metal with a finger. Now you can remove the overhanging flakes with a clean flat brush by spreading them horizontally over the decorative metal surface.
- 8** For sealing, spread accurately the Deco Metal Protective Varnish with a fine clean brush onto the metallic surface. Let it dry well.
- 9** Open wide the ringlet by using two flat pliers. Hold firmly the ringlet with one pair of pliers while the gap of the ringlet is facing up, now open the ringlet backwards by using the second pair of pliers. Hang in the jewellery-cement pendant and the element chain. Close the ringlet by using the both pliers.

# Rayher.

KALEIDO 1 Brasov,  
KALEIDO 2 Brasov, str. Dr. Liviu Cimpeanu nr.47  
Tel : 0726 244 171

[www.rayherhobby.ro](http://www.rayherhobby.ro)

sos. Cristianului nr.1-3  
Tel : 0726 244 174

[www.kaleido.ro](http://www.kaleido.ro)

